




INSTALLATION INSTRUCTIONS



Nominal pipe diameter	40	50	63	75	90	110	125	160
Maximum hole size	60	73	80	92	107	127	133	168
Segment number of the needed fire collar	15	18	20	23	26	29	33	2× 40
Number of clips to be installed	3					4		

